







—
INSTALLATION INSTRUCTION

Parallel connection kit

OZXA38-39




OZXA38



* Stranded

OZXA39





Contact us

ABB Oy

Protection and Connection

P.O. Box 622

FI-65101 Vaasa

Finland

<https://www.abb.com/low-voltage>