



—
INSTALLATION INSTRUCTION

Parallel connection kit


OZXA40-41



OZXA40



OZXA41





Contact us

ABB Oy

Protection and Connection

P.O. Box 622

FI-65101 Vaasa

Finland

<https://www.abb.com/low-voltage>