



—
INSTALLATION INSTRUCTION

Adapter handle


OH_S7, OH_S8



OH_S7



OH_S8





Contact us

ABB Oy

P.O. Box 622
FI-65101 Vaasa
Finland

abb.com/lowvoltage