

PETK

Power & End Termination Kit

INSTALLATION PROCEDURES

- PETK-1 for BSX, RSX, VSX
- PETK-2 for KSX, HTSX
- PETK-3 for HPT, FP
- PETK-3-ECM for HPT, FP
- PETK-3-ZT for HPT, FP

Order separately to be used in conjunction with Thermon connection kits



The Heat Tracing Specialists®

The following installation procedures are guidelines for the installation of the Power and End Termination Kit. For translations other than English and local language translation provided here, please contact Thermon. The English language installation procedure shall govern.

Receiving, Storing and Handling . . .

1. Inspect materials for damage incurred during shipping.
2. Report damages to the carrier for settlement.
3. Identify parts against the packing list to ensure the proper type and quantity has been received.
4. Store in a dry location.

PETK Power and End Termination Kits (per cable)

PETK-1	for BSX, RSX, VSX
PETK-2	for KSX, HTSX
PETK-3	for HPT, FP
PETK-3-ECM	for HPT, FP
PETK-3-ZT	for HPT, FP

Kit Contents . . .



Item	Qty.	Description
1	1	RTV Tube
2	1	Power Connection Boot
3	1	End Cap
4	1	Tape Strip (PETK-3 Only)
5	1	End Termination Caution Label
6	1	Grommet (For PETK-3 Terminator kits only)
7	1	Ground Sleeve

Note:

Wire pins may be required as per client/project specification (order separately).

Warnings . . .

- Due to the risk of electrical shock, arcing and fire caused by product damage or improper usage, installation or maintenance, a ground-fault protection device is required.
- Installation must comply with Thermon requirements (including form PN 50207U for Ex systems) and be installed in accordance with the regulations as per the norm EN IEC 60079-14 for hazardous areas (where applicable), or any other applicable national and local codes.
- Component approvals and performance ratings are based on the use of Thermon specified parts only.
- De-energize all power sources before opening enclosure.
- Keep ends of heating cable and kit components dry before and during installation.
- Minimum bending radius of heating cable is 32 mm (except HPT is 57 mm and FP is 19 mm).
- Individuals installing these products are responsible for complying with all applicable safety and health guidelines. Proper Personal Protective Equipment (PPE) should be utilized during installation. Contact Thermon if you have any additional questions.

Tools Required . . .



PETK Certifications/Approvals¹ . . .

FMG 10.0022X Ex eb IIC T4-T6, Ex tb IIIC T135°C-T85°C

 1725 Ex II 2 GD Ex eb IIC T4-T6, Ex tb IIIC T135°C-T85°C, FM 10ATEX0058X



Note:

1. These sets have been evaluated as components of Thermon's Approved connection kits, such that the area use ratings depend on the rating of the connection kits.



The Heat Tracing Specialists®

PETK

INSTALLATION PROCEDURES


IMPORTANT!

Heating cable must be properly installed within expediter assembly and mounted to pipe prior to terminating with PETK kit.

See Terminator Installation Instructions for expediter mounting details.




Terminator: Route cable through base entry and mount expediter to pipe using pipe band. Do not band over cable.



For HPT and FP cable exchange grommet supplied in Terminator kit with:
 GRW-G provided in PETK-3
 GRW-GT2 provided in PETK-3-ECM
 GRW-G/Tstat provided in PETK-3-ZT

Step 1: Remove Heating Cable Overjacket and Separate Metallic Braid to Form Pigtail



1a. Cut and remove heating cable overjacket.



Do not cut metallic braid.




1b. Separate braid strands at edge of overjacket and pull cable through opening in braid.




1c. Twist braid into a pigtail. Trim ends of braid.

Step 2: Matrix Removal for BSX, RSX, HTSX, KSX, and VSX Cables




2a. Cut and remove primary insulation jacket (BSX and RSX cables only).



2b. Cut a 4mm strip of conductive matrix between the conductors.




Do not cut bus wire strands.




2c. Cut and remove the 4mm matrix strip.

Step 2: Heating Element Removal for HPT and FP Cables




2a. Cut and remove primary insulation jacket.

NOTE: Bus connection must be no more than 50 mm (2") from pipe as addressed in connection kit instructions.



2b. Cut and remove fiberglass overlay and heating element. Push any remaining heating element wire under the primary insulation jacket.




2c. Cut and remove pairing jacket.




Do not cut bus wire insulation.


Step 3: Install Power Boot on Heating Cables



3a. Apply RTV sealant to cable to cover distance of at least 3mm and slide boot onto the end of the cable.




3b. Slide boot onto the end of the cable and green/yellow ground sleeve over twisted braid. Expose 13mm (0.5") of bus wire.




3c. Crimp conductor wire pins on each conductor and on twisted braid if required as per client/project specification (order separately).




Step 4: End Termination for BSX, RSX, HTSX, KSX, and VSX Cables



4a. Cut and remove heating cable overjacket.




4b. Trim away exposed braid from cable.




4c. Fill the end cap with RTV sealant and apply a circumferential bead to cable [minimum of 3 mm (0.12") wide]. Slide end cap onto end of cable.


Step 4: End Termination for HPT and FP




4a. Trim the cable 75 mm (3") from the bus connection.




4b. Cut and remove overjacket and trim away exposed braid from cable.



4c. Cut and remove primary insulation jacket.




4d. Cut and remove fiberglass overlay and heating element. Push any remaining heating element wire under the primary insulation jacket.



4e. Cut and remove pairing jacket. Stagger cut one of the bus wires.




Do not cut bus wire strands.




4f. Tape bus wires individually and then together. Continue taping to cover overjacket. Fill the end cap with RTV sealant and apply a circumferential bead to cable [minimum of 3 mm (0.12") wide]. Slide end cap onto end of cable.

Cable Take-off for BSX, RSX, HTSX, KSX and VSX




For Power Connector Boot Termination



For End Cap Termination

NOTE:
Images may not be printed to scale.

Cable Take-off for HPT and FP Heating Cables



For Power Connection Boot Termination

For End Cap Termination

NOTE:
Images may not be printed to scale.



THERMON . . . The Heat Tracing Specialists®
www.thermon.com

European Headquarters
Boezenweg 25 • PO Box 205
2640 AE Pijnacker • The Netherlands
Phone: +31 (0) 15-36 15 370

Corporate Headquarters
100 Thermon Dr. • PO Box 609
San Marcos, TX 78667-0609 • USA
Phone: +1 512-396-5801

For the Thermon office nearest you
visit us at . . .
www.thermon.com

